


534399

PARTS BREAKDOWN



Component	Item Description
535893	Air Die Grdr Angle-Chuck Casin 534399
535796	Air Die Grdr Angle-"O"Ring 534399
535768	Air Die Grdr Angle-Valve 534399
535812	Air Die Grdr Angle-Spring 534399
535817	Air Die Grdr Angle-"O"Ring 534399
535818	Air Die Grdr Angle-"O"Ring 534399
535873	Air Die Grdr Angle-Vane Set(4) 534399
535884	Air Die Grdr Angle-F/End Plate 534399
535888	Air Die Grdr Angle-Beval Gear 534399
535889	Air Die Grdr Angle-Beval Gear 534399
535842	Air Die Grdr Angle-R/End Plate 534399

AT-7034

No.	Part No.	Description	QTY.
01	KL-20401	Inlet Bushing	1
02	KL-20402	Exhaust Deflector	1
03	KL-20403P	Housing	1
04	KL-20404S	Safety Throttle Lever	1
05	KL-20314	Pin	1
06	KL-20408	Valve	1
07	KL-20408	*O*Ring	1
08	KL-20407	Throttle Valve	1
09	KL-P0004	*O*Ring	1
10	KL-20409	Spring	1
11	KL-20410	Air Regulator	1
12	KL-P0007	*O*Ring	1
13	KL-P010A	*O*Ring	1
14	KL-20413	Valve Screw	1
15	KL-16962	Bearing	2
16	KL-20415	Rear End Plate	1
17	KL-20416	Pin	1
18	KL-20417	Cylinder	1

No.	Part No.	Description	QTY.
19	KL-20418	Rotor	1
20	KL-20419	Rotor Blades	4
21	KL-20420	Washer	1
22	KL-20421	Ball	2
23	KL-204G21	Front End Plate	1
24	KL-16082	Bearing	2
25	KL-204G23	Nipple	1
26	KL-204G24	Bevel Gear	1
27	KL-204G25	Nut	1
28	KL-204G26	Angle Head	1
29	KL-204G34	Gear Oiler	1
30	KL-204G27	Bevel Gear	1
31	KL-204G30	Bearing Cap	1
32	KL-204TG29	Chuck Casing	1
33	KL-204G28	Key	1
34	KL-20328	Collet	1
35	KL-20428	Collet Nut	1
36	KL-20429	Wrench	2