


535400

PARTS BREAKDOWN



Component	Item Description
535401	A/Sander R/O Valve 535400
535402	A/Sander R/O Air Regulator Nut 535400
535403	A/Sander R/O O Ring 535400
535404	A/Sander R/O Spring 535400
535405	A/Sander R/O O Ring 535400
535406	A/Sander R/O Air Regulator Nut 535400
535407	A/Sander R/O Muffler 535400
535408	A/Sander R/O Blades (5) 535400
535409	A/Sander R/O Cylinder 535400
535410	A/Sander R/O O Ring 535400
535411	A/Sander R/O Needle Bearing 535400
535412	A/Sander R/O Spindle 535400
535413	A/Sander R/O Sanding Pad 535400
535414	A/Sander R/O Retaining Ring 535400
535415	A/Sander R/O Lock Ring 535400
535416	A/Sander R/O Guard 535400
524495	Air Sander 6" Regulator Suit 535400 H/D Random Orbital
524496	Air Sander 6" Throttle Valv Suit 535400 H/D Random Orbital
524497	Air Sander 6" 'O' Ring R0401 Suit 535400 H/D Random Orbital
524498	Air Sander 6" 'O' Ring R090 Suit 535400 H/D Random Orbital
524499	Air Sander 6" Rt Blade Set Suit 535400 H/D Random Orbital

Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	60301	Motor Housing	17	60317	Pin (2.5x30L)
2	60302	Rivet	18	60318	Cylinder
3	50103	Air Inlet	19	60319	Retaining Ring (STW-10)
4	60304	Throttle Lever	20	60320	Counterbalance
5	60305	Throttle Valve	21	60321	Key
6	60306	Air Regulator	22	60322	Washer
7	60307	O-Ring (9.8x2.4)	23	60323	O-Ring (59.5x2)
8	51208	Valve Spring	24	060324	Needle Bearing (BA85)
9	70107	O-Ring (4.8x1.9)	25	60325	Retaining Ring (STW-12)
10	60310	Valve Screw	26	60326	Spindle
11	60311	Muffler	27	60327-13	Sanding Pad (6")
12	60312	Retaining Ring (2) (ETWJ-2.3)	28	60328	Internal Ring (RTW-28)
13	051220	Ball Bearing (2) (6000zz)	29	60329	Lock Ring
14	60314	End Plate (2)	30	60330	Guard
15	60315	Rotor	31	060331	Ball Bearing (77R8)
16	60316	Rotor Blade (5)	35	52227	Spanner