


532403

PARTS BREAKDOWN



Component	Item Description
525192	Drill Floor 12Sp-Spring/Case 532403- 46 & 47
536171	Drill Floor 12Sp Column Flange 532403
534945	Drill 12Sp Switch 532403
534934	Drill 12Sp Spring Case\525192 532403
532461	Drill 12Sp Motor 1-1/2Hp 532403-68
524325	Drill Floor Work Table 532403-18
525190	Drill Floor 12Sp-Set Screw 532403-21
525193	Drill Floor 12Sp-Nylon Nut 532403-49
525194	Drill Floor 12Sp-Quill 62*237 532403-52
525195	Drill Floor 12Sp-Spindle 532403-54
525197	Drill Floor 12Sp Motor Pulley 532403-73
525198	Drill Floor 12Sp-Spindle Pully 532403-64
525201	Drill Floor 12Sp-Middle Pulley 532403-86
525202	Drill Floor 12Sp-Pivot Bracket 532403-88
525185	Drill Floor 12Sp ShAFting Rod 532403-9
525189	Drill Floor 12Sp Rack Coll D92 532403-20
525183	Drill Floor 12Sp Tbl Bckt D92M 532403-5
525184	Drill Floor 12Sp Worm Gear 532403-8
525188	Drill Floor 12Sp Rack L812mm 532403-19
525199	Drill Floor 12Sp-Nut 532403-63
525182	Drill Floor 12Sp Base 532403-1
525334	Drill Floor Handle Knob(Large) 532403 / 532440
533860	Drill Crank Handle 532440 532403
582027	Vee Belt A27 (Also Suit 532403)

<u>532444</u>	Drill Bench Switch 532401/402-78 532403
<u>582038</u>	Vee Belt A38 (Also Suit 532403)

532403

PARTS BREAKDOWN



Parts No.	Description	Parts N No.	Description
1.	Base	51.	Middle Pulley
2.	Flange	52.	Pivot Bracket
3.	Washer	53.	Power Cord
4.	Screw	54.	Cable Portection
5.	Column	55.	Thumb Screw
6.	Rack	56.	Screw
7.	Shafting Rod	57.	Wire fixed buckle
8.	Set Screw	58.	Screw
9.	Table Bracket	59.	Switch
10.	Clamp Bolt	60.	Nylon Nut
11.	Table Tilting Label	61.	Spring Cover
12.	Work Table	62.	
13.	Screw	63.	Name Plate
14.	Washer	64.	V-Blet
15.	Nut	65.	Nut
16.	Worm and Worm Gear	66.	Sprindle Pulley
17.	Rack Collar	67.	Retaining Ring
18.	Set Screw	68.	Drive Taper
19.	Handle Body	69.	Ball Bearing
20.	Handle	70.	Ball Spacer
21.	Knob	71.	Retaining Ring
22.	Stop Pin	72.	Retaining Ring
23.	Feed Pinion	73.	Ball Bearing
24.	Thumb Screw	74.	Rubber Washer
25.	Scale	75.	Quill
26.	Scale Sleeve	76.	Wedge
27.	Zero Mark	77.	Ball Bearing
28.	Spring Pin	78.	Spindle
29.	Head	79.	Morse Taper Arbor
30.	Set Screw	80.	Chuck key
31.	Adjusting Bolt C	81.	Chuck
32.	Thumb Screw		
33.	Mounting Plate		
34.	Motor		
35.	Washer		
36.	Nut		
37.	Nut		
38.	Washer		
39.	Shaft Lever		
40.	Adjusting Bolt B		
41.	Washer		
42.	Screw		
43.	Screw		
44.	Pulley Cover		
45.	Screw		
46.	Set Screw		
47.	Motor Pulley		
48.	Knob		
49.	Ball Bearing		