


534360

PARTS BREAKDOWN



### Parts List of AT-7036/AT-7037

| INDEX NO. | DESCRIPTION               | REQ'D NO. | INDEX NO. | DESCRIPTION            | REQ'D NO. |
|-----------|---------------------------|-----------|-----------|------------------------|-----------|
| 01        | Motor Housing             | 1         | 29        | Bevel Pinion           | 1         |
| 02        | Seal Plate                | 1         | 30        | O-Ring                 | 1         |
| 03        | Ball Bearing              | 1         | 39        | Exhaust Deflector      | 1         |
| 04        | Arbor                     | 1         | 40        | Tapping Screw          | 2         |
| 05        | Ball Bearing              | 1         | 41        | Plug                   | 1         |
| 06        | Woodruff Key              | 1         | 42        | O-Ring                 | 1         |
| 07        | Bevel Gear                | 1         | 43        | Flange                 | 1         |
| 08        | Wave Washer               | 1         | 45        | 4" Grinding Wheel      | 1         |
| 09        | External Stop Ring        | 1         |           | 4 1/2" Grinding Wheel  | 1         |
| 10        | Gasket                    | 1         |           | 5" Grinding Wheel      | 1         |
| 11        | Retainer                  | 1         | 46        | Flange Nut             | 1         |
| 12        | 4" Center Wheel Guard     | 1         | 47        | Handle                 | 1         |
|           | 4 1/2" Center Wheel Guard | 1         | 48        | Wrench (A)             | 1         |
|           | 5" Center Wheel Guard     | 1         | 49        | Wrench (B)             | 1         |
| 13        | Spring Washer             | 5         | 50        | Ball Bearing           | 2         |
| 14        | Hex Socket Head Cap Bolt  | 5         | 51        | Throttle Valve Housing | 1         |
| 15        | Rotor                     | 1         | 52        | Bushing                | 1         |
| 16        | Front End Plate           | 1         | 53        | Air Inlet Bushing      | 1         |
| 17        | Cylinder                  | 1         | 54        | Valve Stem             | 1         |
| 18        | Spring Pin                | 1         | 55        | Valve Spring           | 1         |
| 19        | Rotor Blade               | 4         | 56        | Throttle Housing       | 1         |
| 20        | Rear End Plate            | 1         | 57        | O-Ring                 | 1         |
| 21        | Governor                  | 1         | 58        | O-Ring                 | 1         |
| 22        | Pendulum                  | 8         | 59        | Throttle Lever         | 1         |
| 23        | Spring Pin                | 2         | 61        | Throttle Lever Lock    | 1         |
| 24        | Plunger                   | 1         | 62        | Torsion Spring         | 1         |
| 25        | Adjust Screw              | 1         | 63        | Spring Pin             | 1         |
| 26        | Spring                    | 1         | 64        | Spring Pin             | 1         |
| 27        | Adjust Nut                | 1         | 65        | Lock Ring              | 1         |
| 28        | Ball Bearing              | 1         | 66        | Coupling Nut           | 1         |