


534666
PARTS BREAKDOWN



AT-6026A

Index No.	Parts No.	Description	Q'ty
1	AR-38001	Air Inlet	1
2	AR-38005	Throttle Lever	1
3	SP-25220	Spring Pin(2.5*22)	1
4	AR-38C11	Handle Throttle	1
5	AR-38035	Throttle Valve	1
7	AR-38003	Valve Stem	1
8	ORP-0032	O-Ring(3*2)	1
9	AR-38002	Spring	1
10	AR-38012	Plug	1
11	ORP-0080	O-Ring(P8)	1
12	AR-38021	Rear Eng Plate	1
13	BB-06262	Bearing	1
14	AR-38050	End Plate Cap	1
15	AR-38A24	Rotor	1
16	AR-38025	Rotor Blade	4
17	AR-38023	Cylinder	1
18	SP-20060	Spring Pin(2*6)	1
19	AR-38028	Front End Plate	1
20	BB-06082	Bearing	1

Index No.	Parts No.	Description	Q'ty
21	AR-38T46	Exhaust Cover	1
23	AR-38C45	Gear Case	1
24	AR-38042	Idler Gear	3
25	304025	Rear Sprindle	1
26	NR-40138	Gear Pin(4*13.8)	3
27	304027	Nibbler Head	1
28	304028	Pushing Rod Bushing	1
29	304029	Pushing Rod	1
30	302A10	Punch	1
31	302A09	Screw	1
32	304032	Dieew	1
33	304033	Nut	1
34	304034	Drive Bushing	1
35	304035	Shaft	1
36	BB-62002	Bearing	2
37	304037	Washing(10*22)	1
39	RTW-030	Stop Ring(R30)	1
40	304040	Nut	1
41	304041	Plug	1