


535400
PARTS BREAKDOWN



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	60301	Motor Housing	17	60317	Pin (2.5x30L)
2	60302	Rivet	18	60318	Cylinder
3	50103	Air Inlet	19	60319	Retaining Ring (STW-10)
4	60304	Throttle Lever	20	60320	Counterbalance
5	60305	Throttle Valve	21	60321	Key
6	60306	Air Regulator	22	60322	Washer
7	60307	O-Ring (9.8x2.4)	23	60323	O-Ring (59.5x2)
8	51208	Valve Spring	24	060324	Needle Bearing (BA85)
9	70107	O-Ring (4.8x1.9)	25	60325	Retaining Ring (STW-12)
10	60310	Valve Screw	26	60326	Spindle
11	60311	Muffler	27	60327-13	Sanding Pad (6")
12	60312	Retaining Ring (2) (ETWJ-2.3)	28	60328	Internal Ring (RTW-28)
13	051220	Ball Bearing (2) (6000zz)	29	60329	Lock Ring
14	60314	End Plate (2)	30	60330	Guard
15	60315	Rotor	31	060331	Ball Bearing (77R8)
16	60316	Rotor Blade (5)	35	52227	Spanner