



535819
PARTS BREAKDOWN







No.	Part. No.	Description	Q'ty
1	13300020	Table	1
2	E0000002	Extension wing	1
3	12700003b	Table insert	1
4	13300002P	Cabinet	1
5	13200004	Motor cover	1
6	10105056a	handle	2
7	10108005	Hand wheel	2
8	13200032	Wheel cover	1
9	13200013	Rod	1
10	J1330001	Angel label	1
11	13200018b	Foot Stand	4
12	11107098	Rubber Feet	4
13	13200019	SIDE BRACKET	1
14	13200021	TOP SHORT BRACKET	2
15	13200023	SIDE BRACKET	1
16	13200022	BOTTOM LONG BRACKET	2
17	13200020	BOTTOM SHORT BRACKET	2
18	13300015	Dust collect plate	1
19	10105069Q	Flange	1
21	13300008	Arbor	1
22	13300011	Rupprt Rack	1
23	13300005	Body	1
24	13200007	Rod	2
25	13300006	Slide	1
26	M133A005	Motor 1.5HP/ 240/50/1PH	1
27	13300012	Motor plate	1
28	13200009	Motor pulley	1
29	13200016L	Lifting screw	1
30	20900028	Bush	2
31	13200014	Arbor	1
32	13200033	Clamp shoe	1
33	13200027	Sleeve	1
34	11105064	Rod cap	1
35	13300017	Angel indicator	1
36	20900022	Gear	2
37	V13207190	Belt	1
38	13300010	Gear cover	1
39	20701006	Bearing	1
42	11105081	Spring	1
43	13200029	Bracket	2
44	12700057	Screw	1
45	12300118J	Riving knife holder	1
46	12300125J	Fixed block	1
47	12700059	Hex. Nut	1
48	12700058	Riving knife Handle	1
49	S009AN04	Nut	1
50	11102020M	Hex. Screw w. washer	1
51	11105080	Spring	1
52	C9001920	Bearing	4
53	13200038	Screw bushing	1
54	12900037	Sleeve	1
55	12700013	Shaft	1
56	C1206202A	Bearing	2
57	C5151102	Bearing	1
58	13200028	Ring	1
59	S0050505M	Set screw M5XP0.8X5	6
60	S0021025M	Hex. Screw M10XP1.5X25	3
61	S0231000M	Spring washer Ø10	3
62	S0211021	Flat washer 10X21X2t	1
63	C1106201	Bearing	1

No.	Part. No.	Description	Q'ty
64	13200031	Position ring	2
65	S0020820M	Hex. Screw M8XP1.25X20	12
66	S0230800M	Spring washer Ø8	36
67	S0210516	Flat washer 8X16X2t	46
68	C5151104	Bearing	1
69	13200040	Position nut	2
70	60102003a	Hex. Screw M5XP0.8X10	1
71	S0210303	Flat washer 5X12X1t	6
72	L0000123	Motor wire	1
73	S0310425	Pin Ø5X25	2
74	S0010820M	Cap screw M8XP1.25X20	2
75	S0010835M	Cap screw M8XP1.25X35	4
76	S0030515M	Philip Hd. Screw M5XP0.8X15	18
77	10105068p	Nut	1
78	S0020625M	Hex. Screw M6XP1.0X25	2
79	S1017W-2	Strain relief	4
80	S0210402	Flat washer 6x19x2t	1
81	S0050810N	Set screw M8XP1.25X10	4
82	S0111400L	Hex. Nut M14XP2.0	1
83	S0021020M	Hex. Screw M10XP1.5X20	1
84	S0210540	Flat washer 5/8"x40X3t	1
85	S0120580	Locking nut 5/8"-11UNC	1
87	S0050510M	Set screw M5XP0.8X10	2
89	S0120800M	Locking nut M8XP1.25	1
90	S0050103	Set screw 1/4"-20UNCX3/8"	4
91	S0210500b	Flat washer 8X22X3t	1
93	S0112000M	Hex. Nut M20XP2.5	1
94	S00505605M	Set screw M6XP1.0X5	4
95	S0110800M	Hex. Nut M8XP1.25	38
96	12300154	Push tool	1
97	S0060820M	SCREW M8XP1.25X20	24
98	13000004a	Riving knife	1
107	S0020640M	Hex. Screw M6XP1.0X40	2
108	S0110600M	Hex. Nut M6XP1.0	2
109	11500006	Bracket	2
110	11500044	Small bracket	1
111	11500045	Hook	1
113	S0110500M	HEX. NUT M5XP0.8	8
114	S0030324	Philip Hd. Screw 3/16"x24UNCX1-1/2"	2
115	W0000007	SWITCH	1
116	10105053G	SWITCH COVER	1
117	10105052p	SWITCH BOX	1
118	L0000132a	Power wire	1
119	21000030	Nut 3/8"	2
121	S0020410	Hex. Screw 1/4"-20UNCX5/8"	1
122	S0230400	Spring washer Ø1/4"	1
123	S0210401a	Flat washer Ø1/4"xØ13x1t	2
124	S0220400	Teeth washer 1/4"	3
135	10105090Q	Wrench	1
136	S0911417	Open end wrench	1
137	S0911012	Open end wrench	1
138	S0910206	L-wrench 6mm	1
139	S0910204	L-wrench 4mm	1
140	S0910203	L-wrench 3mm	1


535819
PARTS BREAKDOWN



A1	13000004	Riving knife	1
A2	12700005	Supporting arm	1
A3	12700006	Guard (left)	1
A4	12700007	Guard (right)	1
A5	12700067	"see thru" plate	1
A6	10606102	Anti-back kick plate	2
A7	10103040	Spring	1
A8	10103035Q	Supporting plate	2
A9	S0030304	Philip Hd. Screw 3/16"-24UNCX1/4"	2
A10	S0120200	Locking nut 1/4"-20UNC	8
A11	S0040412	Flat Hd. Screw 1/4"-20UNCX5/8"	8
A12	S0210404	Flat washer 1/4"X23X3t	8
A13	S0310630	Pin Ø6-30	1
A14	S0313528	Pin Ø3.5-28	1
A15	S0310528	Pin Ø5-28	1
A16	S05ETW07	E-Ring	2
A17	12700051a	Sleeve	1
A18	12700039a	Pad	1


A19	S0120600M	Locking nut	2
A20	S0010635M	Cap screw M6XP1.0X35	1
A21	12700054	Handle	1
A22	12700061	Fixed plate	1
A23	S0310530	Pin Ø5-30	1
A24	12700062	Guard	1
A25	S0010512M	Cap screw M5XP0.8X12	2
A26	12700038	Supporting plate	2
A27	JG133001	Warning label	1
B1	10104046	Miter gauge	1
B2	10104048c	Guide bar	1
B3	10104045	Handle	1
B4	10104050	Indicator	1
B5	10104049Q	Position plate	1
B6	10104047	Pad	1
B7	S0210501	Flat washer	1
B8	S0030110	Philip Hd. Screw 5/32"X32UNCX5/8"	3
B9	S0110100	Hex. Nut 5/32"	3
B10	S0050404	Set screw 1/4"-20UNCX1/4"	1
B11	S0310306	Pin Ø3X6	1
B12	S0040400	Flat Hd. Screw 1/4"X20UNCX1/4"	1
B13	10104047k	Pin Ø8X20MM	1

535819
PARTS BREAKDOWN



NO.	DESCRIPTION	Q'TY	MS NO.
1	FENCE BODY	1	11000001a
3	FENCE SIDEBOARD	2	11000008b
4	FENCE CAP	1	11000021
5	FENCE SIDEBOARD CAP	4	11000022
6	SCREW 5/16"-18UNC	1	11001021k
7	CLAMP BLOCK	1	11003003
8	HANDLE	1	11000004G
9	KNOB	1	11000005
12	CLEAR INDICATOR	1	11000015
14	PLASTIC PAD (SLIDER) 19*50*2t	2	11000024
15	SOCKET SET SCREW 5/16"-18UNC*1/4"	2	S0050504
16	WASHER 3/16	2	S0210300
17	PHILIP HEAD SCREW 3/16"-24UNC *3/4"	2	S0030318
18	HEX. SCREW 3/8"-16UNC*1 3/4"	1	S0020601
19	HEX.HEAD SCREW 1/4"-20UNC*1 3/4"	1	S0020425
20	LOCK NUT 1/4"-20UNC	1	S0120200
21	LOCK NUT 3/8"-16UNC	1	S0120300
22	SELF-TAPPING SCREW 3/16"-5/8"	12	S0070300
23	HEX. NUT 5/16"-18UNC	1	S0110500
24	WARNING LABEL (LONG)	1	J11FB201
25	WARNING LABEL(SHORT)	1	J11FB202
26	PLASTIC PAD (SLIDER) 19*50*1.2t	2	1100025
27	SPRING	1	11105080
29	CAP SCREW 5/16"-18UNC*1"	4	S0010501
30	REAR RAIL RACK	1	11000033G
31	FRONT RAIL COVER	2	11003002G
32	FRONT RAIL	1	11000034G
33	FLAT HEAD SCREW 5/16"-18UNC-1"	4	S0040307
34	FRONT RAIL RACK	1	11000032G
35	HEX. HEAD SCREW 1/4"-20UNC-3/4"	6	S0020412
36	LONG SCALE 30"	1	11000018
37	NYLON SCREW M12*1.75-12L	2	11003017
38	WASHER 5/16"	8	S0210500
39	HEX. NUT 5/16"-18UNC	4	S0120500
40	TIGHTENING ROD PLATE	1	11001010a
42	PIN	1	S0310506

535819
PARTS BREAKDOWN



No.	DESCRIPTION	PART NO	Q'TY
1	Movable table (left)	12200001	1
2	Movable table (right)	12200002	1
3	Guard	12200003	1
4	Connecting Sheet	12200004	1
5	Slideway	12200005	1
5A	Slideway	12200005A	1
6	Connecting Plate	12200006	1
7	Rail	12200007	2
8	Support Plate	12200008	1
9	Support Block	12200009	2
10	Ball	12200010	2
11	Spring	12200011	2
12	Self-Tap Screw 5/32"-32uncx1/2"	S0070203	4
13	Hex Screw 1/4"-20uncx3/8"	S0020409	24
14	Square head bolt 1/4"-20unc	S0000112A	2
15	Nut	S0110409	28
16	Rubber Pad	12200012	4
17	Washer 1/4"	S0210403	2
18	Cross hd screw 1/4"-20uncx3/8"	S0050404	16
19	Cross hd screw 3/16"-24uncx1/4"	S0030304	6
20	Cross hd screw 3/16"-24uncx1"	S0030301	2
21	Hex Screw 5/16"-18uncx1"	S0020501a	2
22	Nut 5/16"-18unc	S0110500	2
23	Washer 5/16"	S0210516	2
24	Hex screw 3/8"-16uncx1"	S0020612	2
25	Washer 3/8"	S0210600	2
26	Guide Bar	11900013	1
27	23*22*12 Locating Plate	10104049	1
28	Plate	11900014	1
29	1/4"-20UNC*1/4" Soc Set Scr	S0050404	1
30	Ø3*6 Roll Pin	S0310306	1

No.	DESCRIPTION	PART NO	Q'TY
31	Ø5*30*20 Pointer	10104050	1
32	1/4"-20UNC*1/4" Scr	S0040400	1
33	R87.5*43 Miter Gauge Body	10104046	1
34	1/4"-20UNC*21 Hand Knob	10104045	1
35	5/32"-32UNC Hex Nut	S0110100	3
36	5/32"-32UNC*1/2" Rd Hd Scr	S0030108	3