



576157

PARTS BREAKDOWN




No.	Drawing no.	Description	Qty.	No.	Drawing no.	Description	Qty.
2	SPIII.1-00	Handle bar	1	29	SP.6-12	Roller	2
3	SPA.0-02	Washer	2	30	GB848-86	Washer 16	4
4	GB93-1987	Washer 12	6	31	GB894.1-86	Retaining ring for axle 16	6
5	GB5781-2000	Bolt 12x30	2	32	SPS.0-01	Shaft	2
6	GB5781-2000	Bolt M8×25	8	33	GB95-1985	Washer 16	4
7	GB95-1985	Washer 8	17	34	GB95-1985	Washer 12	4
9	GB93-1987	Washer 8	9	35	GB41-86	Nut M12	4
10	GB41-86	Nut M8	9	36	SP.6-10	Roller	2
11		Universal wheel 5"	2	37	SP.6-01	Bush	2
12	SPSC.3-00	Frame	1	38	SP.0.02	L-Pin	4
13	SP.0-08	Shaft	2	39	GB70-85	Bolt 6x10	4
14	SP.0-04	Wheel 5"	2	40	SP.0-03	Shaft	1
15	GB894.1-86	Retaining ring for axle 12	2	41	SPS.4-00	Arm	1
17	SP.0-11	Shaft	1	42	SF-1.1612	Bush	2
18	SP.0-12	Bush	1	47	YQ-00-350	Pump unit	1
19	GB894.1-86	Retaining ring for axle 10	1	48	SPC.6-07	Support	2
20	SPS.0-03	Shaft	1	49	SPA.4-07	Washer	2
21	YQ-7	Retaining ring	1	50	GB894.1-86	Retaining ring for axle 24	2
22	GB894.1-86	Retaining ring for axle 20	2	51	GB93-1987	Washer 6	4
23	SPS.2.01B	Connecting rod	1	53	YQ-8	Retaining ring	1
24	SP.3-03	Cushion	1	54	SP.0-06	Bush	4
25	GB5781-2000	Bolt M8x30	1	55	SP.0-07	Hollow shaft	2
26	SP.3-02	Pedal bar	1	56	GB276-86	Bearing 6203	4
27	SPSC.6-00	Table	1	57	SPS.5-00	Arm	1
28	SP.6-11	Bush	2				

576157
PARTS BREAKDOWN



No.	Drawing no.	Description	Qty.	27	YQ-01	Strike pin	1	
1	GB3452.1-86	O-ring 22.4×2.65	1	28	GB3452.1-82	O-ring 6.9×1.8	2	
2	SP.8-11A	Pump cylinder	1	29	DF1.2-08	Shaft	1	
3	UHS14	Yx- seal ring	1	30		Filter	1	
4	DH14	Dust ring	1	31	GB3452.1-82	O-ring 65×3.55	1	
5	SP.8-10A	Pump plunger	1	32	SP.8-12	Rectangular ring section	1	
6	SP.8-09	Spring	1	33	SP.8-04	Cylinder	1	
7	SP.8-08	Spring seat	1	34	SP.8-03	Housing	1	
8	GB894.1-86	Retaining ring for axle 10	1	35	SP.8-02	Screw	1	
9	SP.0-13B	Joint plate	2	36	GB894.1-86	Retaining ring for axle 25	1	
10	SP.0-14	Pin	1	37	SP.8-13	Washer	1	
11	JF.1-17	Screw	1	38	GB3452.1-82	O-ring 33.5×3.55	1	
12	JB982-77	Copper washer 20	1	39	SP.8-14	Cup packing	1	
13	6W804.1-12	Damp valve	1	40	SP.8-06	Bush	1	
14	YQ-03	Spring	1	41	GB3452.1-82	O-ring 20×2.65	1	
15	YQ-02	Spring seat	1	42	SP.8-05	Piston rod	1	
16	GB308-77	Steel ball 6.35	2	43	CO1.2-16	Rectangular section sealing	1	
17	GB308-77	Steel ball 4.5	1	44	SP.8-01	Cylinder cap	1	
18	SP.8-18	Spring seat	1	45	GB3452.1-82	O-ring 31.5×3.55	1	
19	SP.8-17	Spring	1	46	HG4-692-67	J Shaped steel frame rubber sealing 32×45×6.5	1	
20	SP.8-16	Adjusting screw	1	47	YQ.6-300	Base	1	
21	GB3452.1-86	O-ring 7.5×2.65	2	48	YQ-04	Lever plate	1	
22	SP.8-15	Cover ring	1	49	GB894.1-86	Retaining ring for axle 8	1	
23	GB308-77	Steel ball 9.5	1					
24	SP.8-07	Spring	1					
25	GB308-77	Steel ball 1/2(12.7)	1					
26	GB77-85	Screw M16×18	1					

576157
PARTS BREAKDOWN



No.	Drawing no.	Description	Qty.	Remark
1	GB879-86	Spring pin 6x30	1	
2	SPAIII.1.01	Handle bar	1	
3	SPIII.1.02	Knob	1	
4	GB6172-86	Nut M8	1	SPS350
5	SPIII.0-01	Screw	2	
6	1340(1135)	Pull rod	4	