



PARTS BREAKDOWN



Part list of OBS-2S6

NO	PART NO	DESCRIPTION	Q'TY	NO	PART NO	DESCRIPTION	Q'TY
01	OB-01	REGULATOR	1	27	OB-26A	BEARING(6002ZZ)	1
02	OB-02	O-RING	2	28	OB-28.1	WASHER	1
03	OB-30	SNAP RING	1	28A	OB-28	WASHER	1
04	OB-04	O-RING	1	29	E-29	WASHER	1
05	OB-05	VALVE STEM	1	30	ST70407	ROTOR KEY	1
06	OB-06	WASHER	1	31	STS560-29	MOTOR SHAFT BALANCER (6"	1
07	OB-16.1	WASHER	1	32	OB-30	SNAP RING	1
08	STOB-08	VALVE	1	33	OB-31.3	BEARING (6001LU)	1
09	OB-09-1	SPRING	1	33A	OB-31.4	BEARING (6001)	1
10	70426	AIR INLET	1	34	81326	PIN(3*8)	1
15	OB-13	LEVER	1	35	OB-33	SNAP RING	1
16	OB-14	PIN	1	36	S560-34	SHAFT	1
17	STOB-15-3	HOUSING	1	37	OB-35.2	HOUSING COVER	1
18	OB-16.2	RUBBER BUSHING	2	38	OB-36	SCREW	4
19	70410	SNAP RING	1	40	BTOB-38-6V6Y	PAD HOOK-UP	1
20	70048A	BEARING (6000ZZ)	1	41	BTOB-39-22	STOP SPANNER	1
21	STOB-19	REAR PLATE	1	42	S560-40	VACUUM ADAPTER	1
22	OB-20	ROTOR BLADE	5	43	OB-42.1A	MUFFLER BODY	1
23	STOB-21	ROTOR	1	46	STOB-46-2	RUBBER HOSE & BAG	1
24	STOB-22	CYLINDER	1	48	S560-47	SHROUD	1
25	OB-24	O-RING	1	49	OB-101-23	PIN (3*14L)	1
26	STOB-25	FRONT PLATE	1	50	OB-23.2A	SHIM	1