




594102
PARTS BREAKDOWN







NO.202 Assembly
47,48,49




NO.201 Assembly
12,29,30,31,32,47,48,49,89




NO.203 Frame Assembly
20,35R,35L,36,37,86



NO.200 Housing Assembly
23,27,28



NO.205 Pusher Assembly
68,69



NO.206 Magazine Assembly
73,75,76,77,80,81,82,83

ITEM	DESCRIPTION	TOOL NO.	PART NUMBER	Q'TY
1	Set Screw		AC01001	1
3	Shakeproof lock Washer		AC01003	7
4	Air Deflector		AC01004	1
5	Rear Valve Seat		AC01005	1
6	O-Ring		AC01006	2
7	Throttle Spring		AC01007	1
8	Throttle Spring Locator		AC01008	1
9	Throttle Valve Screw		AC01009	2
10	Valve Screw Washer		AC01010	2
11	O-Ring Support		AC01011	4
12	O-Ring		AC01012	5
13	O-Ring Center Support		AC01013	2
14	Throttle Valve Spacer		AC01014	1
16	Front Valve Seat		AC01016	1
17	Throttle Stem		AC01017	1
18	Button Head Cap Screw		AC01018	1
20	Trigger Guard		AC01020	1
21	Flexloc Nut		AC01021	2
23	Stud		AC01023	2
27	Housing		AC01027	1
28	Set Screw		AC01028	2
29	O-Ring		AC01029	1
30	Piston		AC01030	1
31	Cylinder Gasket		AC01031	1
32	Piston Stop Spacer	AC02	AC02032	1
		AC03	AC01032	
		AC04	AC01032	
35R	Side Plate (Right)		AC0135R	1
35L	Side Plate (Left)		AC0135L	1
36	Roll Pin		AC01036	3
37	Trigger		AC01037	1
39	Socket Head Cap Screw		AC01039	4
40	Upper Jaw	AC02	AC02040	1
		AC03	AC03040	
		AC04	AC04040	
41	Jaw Bushing		AC01041	2
43	Latch Pin Clip		AC01043	1
44	Latch Spring		AC01044	1
45	Latch	AC02	AC01045	1
		AC03	AC03045	
		AC04	AC03045	

ITEM	DESCRIPTION	TOOL NO.	PART NUMBER	Q'TY
46	Roller	AC02	AC02046	4
		AC03	AC01046	
		AC04	AC01046	
47	Feeder Blade	AC02	AC02047	1
		AC03	AC03047	
		AC04	AC03047	
48	Piston Rod	AC02	AC02048	1
		AC03	AC03048	
		AC04	AC03048	
49	Roller Pin		AC01049	1
50	Lower Jaw	AC02	AC02050	1
		AC03	AC03050	
		AC04	AC04050	
51	Feeder Arm		AC01051	1
56	Washer		AC01056	2
57	Nut		AC01057	4
58	Screw		AC01058	2
59	Inlet Bushing		AC01059	1
64	Socket Head Cap Screw		AC01064	1
67	Nut		AC01067	1
68	Pusher		AC02068	1
69	Extruded Rivet		AC01069	1
70	Pusher Spring		AC01070	1
71	Button Head Screw		AC01071	1
73	Magazine Body		AC02073	1
74	Jaw Bolt		AC02074	2
75	Magazine Spring		AC02075	2
76	Magazine Shoe		AC02076	1
77	Roll Pin		AC02077	1
78	Magazine Shim		AC01078	1
78A	Magazine Shim		AC0178A	1
79	Washer		AC01079	2
80	Guard		AC02080	2
81	Guard Screw		AC02081	1
82	Clip Anti-Backup		AC02082	1
83	Screw		AC02083	1
86	Plate Screw		AC01086	1
89	Flexloc Nut		AC01089	3
204	Feeder Guid Rail		AC02204	1