


PARTS BREAKDOWN



KCT-C2

1	HEX.SDC.HD.BOLT	41	SPRING
2	SUPPORT	42	GUIDE
3	END CAP	43	PIN
4	CAP SEAL	44	PUSHER SPRING
5	MAIN PISTON	45	ROLLER
6	O-RING	46	GUIDE
7	SLEEVE	47	JAW (LONG)
8	O-RING	48	JAW (LONG)
9	BOLT SCREW	49	SAFETY GUIDE
10	COVER	50	SLEEVE
11	VALVE SEAT	51	TRIGGER
12	O-RING	52	GUIDE
13	TRIGGER SPRING	53	GUIDE
14		54	PIN
15	HEX.SDC.HD.BOLT	55	STOP GUIDE
16	WASHER	56	WASHER
17	WASHER	57	NUT
18	O-RING	58	BOLT SCREW
19	TRIGGER SEAT	59	STOP GUIDE
20	O-RING	60	HEX.SDC.HD.BOLT
21	WASHER	61	PUSHER
22	TRIGGER VALVE STEM	62	PIN
23	SET SCREW	63	NUT
24	BODY	64	PIN
25	WASHER	65	DRIVER
26	O-RING	66	ROLLER PIN
27	WASHER	67	ROLLER
28	O-RING	68	ROLLER
29	WASHER	69	DRIVER PLATE
30	WASHER	70	HEX.SDC.HD.BOLT
31	HEX.SDC.HD.BOLT	71	BOLT SCREW
32	O-RING	72	SPRING GUIDE
33	TRIGGER SEAT	73	SAFETY GUIDE
34	VALVE STEM	3A	CAP SEAL
35	BOLT SCREW	5A	NUT
36	BOLT SCREW		
37	HEX.SDC.HD.BOLT		
38	BOLT SCREW		
39	GUIDE		
40	WASHER		