


595979
PARTS BREAKDOWN



Item Code	Alternate Code	Extended Description
510294	595979-01	Diamond core drill 80mm 1800W Shaft 595979-01
510295	595979-03	Diamond core drill 80mm 1800W Inlet valve 595979-03
510296	595979-05	Diamond core drill 80mm 1800W water seal 595979-05
510297	595979-07	Diamond core drill 80mm 1800W Bearing 595979-07
510298	595979-09	Diamond core drill 80mm 1800W Small iron sets 595979-09
510299	595979-11	Diamond core drill 80mm 1800W Auxiliary handle 595979-11
510301	595979-15	Diamond core drill 80mm 1800W Bearing 595979-15
510302	595979-17	Diamond core drill 80mm 1800W Clutch iron plate 595979-17
510303	595979-19	Diamond core drill 80mm 1800W Clutch Flat 595979-19
510304	595979-21	Diamond core drill 80mm 1800W Clutch Nut 595979-21
510305	595979-23	Diamond core drill 80mm 1800W Spindle iron sets 595979-23
510306	595979-25	Diamond core drill 80mm 1800W Bearing 595979-25
510307	595979-27	Diamond core drill 80mm 1800W Pin dial file 595979-27
510308	595979-29	Diamond core drill 80mm 1800W Gearbox pin 595979-29
510309	595979-31	Diamond core drill 80mm 1800W Spring 595979-31
510310	595979-33	Diamond core drill 80mm 1800W Plastic dial button 595979-33
510311	595979-35	Diamond core drill 80mm 1800W Word shift screw 595979-35
510312	595979-37	Diamond core drill 80mm 1800W Bearing 6000 595979-37
510313	595979-39	Diamond core drill 80mm 1800W Bearing 595979-39
510315	595979-43	Diamond core drill 80mm 1800W Stator 595979-43
510317	595979-47	Diamond core drill 80mm 1800W Brushes 595979-47
510318	595979-49	Diamond core drill 80mm 1800W Speed governor 595979-49
510320	595979-53	Diamond core drill 80mm 1800W Switch 595979-53
510322	595979-02	Diamond core drill 80mm 1800W Oil Seal 595979-02
510324	595979-06	Diamond core drill 80mm 1800W Circlip 595979-06
510325	595979-08	Diamond core drill 80mm 1800W Tighten screws 595979-08
510326	595979-10	Diamond core drill 80mm 1800W Handlebar clamp 595979-10
510328	595979-14	Diamond core drill 80mm 1800W Gearbox 595979-14
510329	595979-16	Diamond core drill 80mm 1800W Clutch shaft 595979-16
510330	595979-18	Diamond core drill 80mm 1800W Clutch Copper sheet 595979-18
510331	595979-20	Diamond core drill 80mm 1800W Clutch spring washer 595979-20
510332	595979-22	Diamond core drill 80mm 1800W Bearing 595979-22
510333	595979-24	Diamond core drill 80mm 1800W Flat gear 595979-24
510334	595979-26	Diamond core drill 80mm 1800W Circlip 595979-26
510335	595979-28	Diamond core drill 80mm 1800W Axle pin DIP file 595979-28
510336	595979-30	Diamond core drill 80mm 1800W E word screws 595979-30
510337	595979-32	Diamond core drill 80mm 1800W Grooved pin 595979-32
510338	595979-34	Diamond core drill 80mm 1800W Spring 595979-34
510339	595979-36	Diamond core drill 80mm 1800W Intermediate cover 595979-36
510340	595979-38	Diamond core drill 80mm 1800W Rotor 595979-38
510341	595979-40	Diamond core drill 80mm 1800W Plastic ring 595979-40
510343	595979-44	Diamond core drill 80mm 1800W stator shell 595979-44
510344	595979-46	Diamond core drill 80mm 1800W Brush holder 595979-46
510345	595979-48	Diamond core drill 80mm 1800W Brush Cover 595979-48
510347	595979-52	Diamond core drill 80mm 1800W Anti-bending joints 595979-52
510349	595979-56	Diamond core drill 80mm 1800W Main handle 595979-56
595981	595979-S	Diamond core drill stand suit 595979 595980

597862	595981-03	Diamond core drill stand adaptor 46mm suit 595979 drill and 595981 Stand
--------	-----------	--